

1012 WSPR-TX_Desktop Serial API as used from software version 1.10

PC User config Set or Get commands			Type of data and number of bytes	User config is sent by the PC configuration software
Description	Send	Set/Get	Data [8..]	Comment
Cmd CurrentMode	{CCM}	S/G	Text 1 S=Sig, W=WSPR, N=None	
Cmd User Config Store in EEPROM	{CSE}	S		
Opt TX Pause	{OTP}	S/G	Text 5 0-99999 Minutes	
Opt StartMode	{OSM}	S/G	Text 1 S=Sig, W=WSPR, N=None	
Opt Band TX Enable	{OBD}	S/G	Text 2 Text 1 - Band number *, E/D E=Enable, D=Disable	
Opt Location	{OLC}	S/G	Text 1. G=GPS calculated, M=Manual (DL4 or DL6 data)	
Opt Locator Precision	{OLP}	S/G	Text 1. 4 or 6 = Number of character used in the Maidenhead report.	
Opt Power	{OPW}	S/G	Text 1. N=Normal using the DPD Power Data. A=Altitude encoded.	
Opt Time Slot	{OTS}	S/G	Text 2 Time Slot Code 0 to 16. 0-4=10 min. schedule, 5-14=20min schedule, 15=Band coordinated Schedule, 16=No schedule	
Opt PreFix/Suffix	{OPS}	S/G	Text1 P=Use Prefix, S=Use Suffix, N=None	
Dat CallSign	{DCS}	S/G	Text 6 Callsign	
Dat Suffix	{DSF}	S/G	Text 3 Suffix code 000-125. 000-009= 0 to 9, 010-035=A to Z	Call Sign suffix code. A / will be automatically appended after the Call Sign followed by the suffix
Dat Prefix	{DPF}	S/G	Text 3 Prefix padded with leading spaces if less than three characters. A-Z and 0-9 allowed	Call Sign prefix chars. A / will be automatically added between the Prefix and the Call Sign
Dat Locator 4	{DL4}	S/G	Text 4 Maidenhead grid with four characters	
Dat Locator 6	{DL6}	S/G	Text 6 Maidenhead grid with six characters	
Dat PowerData	{DPD}	S/G	Text 2 Power in dBm. Pading with a leading zero to two characters 0-60dBm	
Dat Name	{DNM}	S/G	Text 40	
Dat Generator Frequency	{DGF}	S/G	Text 12 Frequency in Centi Hertz. Paded with leading zeros to 12 characters	
Debug Set LP Filter	{CSL}	S	Text 1. Text1=A,B,C or D for LP bank.	LP filters are automatically set by the WSPR Beacon and Signal Gen. routines but can be temporarily overrided by this command for testing purposes

PC Factory config Set or Get commands			Type of data and number of bytes	Factory data is sent by the PC Factory configuration software
Description	Send	Set/Get	Data [8..]	Comment
Factory Product model Number	{FPN}	G	Text 5 0-65534	1011=WSPR-TX_LP1, 1012=WSPR Desktop, 1017=WSPR Mini
Factory Hardware Version	{FHV}	S/G	Text 3 0-255	
Factory Hardware Revision	{FHR}	S/G	Text 3 0-255	
Factory Software Version	{FSV}	G	Text 3 0-255	
Factory Software Revision	{FSR}	G	Text 3 0-255	
Factory Reference Oscillator Frequency	{FRF}	S/G	Text 9 Frequency in Hertz. Paded with leading zeros to 9 characters	Normally 026000000
Factory Low Pass Filter installed	{FLP}	S/G	Text 1 A,B,C or D for indicating or setting bank of low pass filter A to D	98=Just a link between input and output - the firmware will use this if no other filter is a good match, 99=Nothing fitted (open circuit) the firmware will never use this as a filter
Cmd FactoryConfig Store in EEPROM	{FSE}	S		

Arduino replies for Get commands			Type of data and number of bytes	Replies from the Arduino in respons to a Get query
Description	Return		Data	
Cmd CurrentMode	{CCM}		Text 1 S=Sig, W=WSPR, N=None	
Opt TX Pause	{OTP}		Text 5 0-99999 Minutes	
Opt StartMode	{OSM}		Text 1 S=Sig, W=WSPR, N=None	
Opt Band TX Enable	{OBD}		Text 2 Text 1. Band number *, E=Enable, D=Disable	
Opt Location	{OLC}		Text 1. G=GPS calculated, M=Manual (DL4 data)	
Dat CallSign	{DCS}		Text 6	
Dat Locator 4	{DL4}		Text 4	
Dat Locator 6	{DL6}		Text 6	
Dat PowerData	{DPD}		Text 2 (00 to 60) dBm	
Dat Name	{DNM}		Text 40	
Dat Generator Freq	{DGF}		Text 12 Frequency in Centi Hertz. Paded with leading zeros to 12 characters	

Arduino Status update messages			Type of data and number of bytes	These messages are sent whenever the Arduino thinks it's appropriate
Description	Return		Data	
Current Mode	{CCM}		Text 1 S=Sig, W=WSPR, N=None	
GPS locator 4 char Maidenhead	{GL4}		Text 4	
GPS Locator 6 char Maidenhead	{GL6}		Text 6	
GPS Time	{GTM}		Text 8 HH:MM:SS	
GPS Lock	{GLC}		Text 1 T=True F=False	
GPS Satellite data	{GSI}		Text2 Text3 Text2 Text2 - ID Az El SNR	
Transmitter Frequency	{TFQ}		Text 5-12 Frequency in centiHz, no leading zeros	
Transmitter On	{TON}		Text 1 T=True F=False	
Microcontroller Paus	{MPS}		Text 7 0-4,000,000Seconds	
Microcontroller Information	{MIN}		Text	
Low Pass filter set	{LPI}		Text 1 A-D	
MicroController VCC Voltage	{MVC}		Text 4 0-9999mV (Normally 3300)	
Transmitter Current Band	{TBN}		Text 2=Band number *	
Transmitter WSPR Symbol	{TWS}		Text 2 Text3 Band number *, WSPR symbol count 0-161	
Transmitter WSPR Band Cycle Complete	{TCC}			

* Band number definitions

- 00=2190m
- 01=630m
- 02=160m
- 03=80m
- 04=40m
- 05=30m
- 06=20m
- 07=17m
- 8=15m
- 9=12m
- 10=10m
- 11=6m
- 12=4m
- 13=2m
- 14=70cm
- 15=23cm